MFOS ELECTRONIC MUSIC 16 STEP SEQUENCER

Steps 1–8

1	2	3	4	5	6	7	8
ON	ON	ON	ON	ON	ON	ON	ON
GATE	GATE	GATE	GATE	GATE	GATE	GATE	GATE
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
COARSE	COARSE	COARSE	COARSE	COARSE	COARSE	COARSE	COARSE
FINE	FINE	FINE	FINE	FINE	FINE	FINE	FINE

Each knob: 0 1 2 3 4 5 6 7 8 9 10

Steps 9–16

9	10	11	12	13	14	15	16
ON	ON	ON	ON	ON	ON	ON	ON
GATE	GATE	GATE	GATE	GATE	GATE	GATE	GATE
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
COARSE	COARSE	COARSE	COARSE	COARSE	COARSE	COARSE	COARSE
FINE	FINE	FINE	FINE	FINE	FINE	FINE	FINE

Each knob: 0 1 2 3 4 5 6 7 8 9 10

SEQ. MODE

ACTION STEP

5 6 7 8 9 10 11 12 13 14 15 16

ACTION AT STEP

NONE — STOP — RESET — REVERSE

USE MODE

RANDOM 16

STOP/RUN

STOP/RUN

RESET

FORWARD

BACK

SEQ. RATE

SEQ. RATE: 0 1 2 3 4 5 6 7 8 9 10

GLIDE: 0 1 2 3 4 5 6 7 8 9 10

GATE OUT	CV/GLIDE OUT	CV/GLIDE OUT
TRIG OUT	CV OUT	CV OUT
CLOCK OUT	EXT CLOCK IN	EXT START